



SUPCO IG402K

Universal Ignitor Kit Installation Data

Replaces: Robertshaw ignitors 41-402, 41-408, 41-410 & 41-411.

To replace these kits see the table below.

To Replace Part Number	Use These Parts
41 - 402	Two wire nuts
41 - 408	Attach two male pins and one "C" terminal connector.
41 - 410	Attach two male pins and one "B" terminal connector.
*41 - 411	Refer to instruction sheet. Attach two male pins, one "C" terminal connector and one mounting bracket.

Parts View:



Wire Nut




Male Pins



Mounting Bracket

*41-411



B Terminal Connector



C Terminal Connector

* **Note** - if needed cut off terminal connector, discard and use the two wire nuts to connect any ignitor.

Sealed Unit Parts Co., Inc.

2230 Landmark Place • Allenwood, NJ 08720 USA

Phone: 732-223-6644 • Fax: 732-223-1617

www.supco.com • info@supco.com

